

Juniper

IVE appliances feature a variety of hardware designs. The hardware installation procedure for your IVE depends upon the specific model of IVE you purchase. The following sections cover hardware installation procedures for the various IVE systems available from Juniper Networks:

- ? "Secure Access 700" on page 2
- ? "Secure Access 2000 and Secure Access 4000" on page 3
- ? "Secure Access 6000" on page 4
- ? "Secure Access 4000 FIPS and Secure Access 6000 FIPS" on page 6
- Secure Access 700

Figure 1: Secure Access 700

The Secure Access 700 ships with mounting ears and rubber feet. Use the mounting ears to rack mount the appliance or attach the rubber feet to place the appliance on a flat surface. Next, connect included cables and power on the IVE following these steps:

1. On the rear panel, plug the power cord into the AC receptacle.
2. On the front panel:
 - a. Plug the Ethernet cable into the "INTERNAL" port. Once you apply power to the IVE, the internal port uses two LEDs to indicate the connection status, which is described in Table 1 on page 8.

Figure 2: The internal port is located on the front panel

NOTE: For Secure Access and Secure Access FIPS safety information, refer to the Juniper Networks Security Products Safety Guide available on the Juniper Networks Support site.
Console port